

VARIOUS SHOCK MOUNTING CENTRES:

Make	Droop inches	Droop mm	Bump inches	Bump mm
Sachs	20.500	520.700	13.500	342.900
Sachs/Boge Automatic	20.750	527.050	13.625	346.075
Monroe R3255	20.125	511.175	15.000	381.000
Koni	21.000	533.400	14.875	377.825
Woodhead	21.000	533.400	15.250	387.350
Armstrong	20.500	520.700	15.000	381.000
Girling	21.125	536.575	15.375	390.525
Motorcraft	20.750	527.050	15.000	381.000
Unipart (black) GDA 4109	21.125	536.575	15.000	381.000
Unipart TR7	20.813	528.638	14.125	358.775
KYB 554017	20.750	527.050	14.375	365.125
Leda my spec Bespoke	18.250	463.550	14.000	355.600

Note: shock travel ratio is 1.51 x spring travel
thus .250 " shock travel = .165" spring travel